

Laundry

Handle Placement for Laundry

North Wall Uppers

96 mm	
Middle of bottom screw	2 3/4" from bottom of door 1 1/2" from inside edge

North Lower drawers

First Row	96mm	centered
Second Row	50mm	centered
Third Row	50mm	centered
	96mm	centered
	96mm	centered
	50mm	centered

South Wall Uppers

4 Uppers	96mm	2 3/4" from bottom of door 1 1/2" from inside edge (same as opposite wall)
Ironing Board	50mm	

Wall Behind Door

62" doors	192mm	11" from bottom of door center of frame left to right
Long door	192mm	same level as 62" doors
Drawers	192mm	centered